

***** Read This Installation Guide Prior to Beginning Installation *****

STEP-1

Inspect new trim to see how section of original trim is attached (with nuts, clips, and/or hooks) to body panel. Remove old molding from car, and carefully clean panel. Application of an auto paint restoration compound followed by a polish or wax may be helpful.



STEP-2

To help ensure snug-fitting new moldings, **URO Parts recommends replacement of old, fragile, and broken plastic molding clips** (Mercedes part number 001 988 76 81). Failure to replace old clips may result in loose moldings.

STEP-3

Installation of body moldings is the reverse of removal.

Recommended Additional Parts

The following moldings attach to body panels with Mercedes-Benz **Molding Clip 001 988 76 81**.

| <u>Molding Section</u> | <u>Clip Qty</u> |
|---------------------------|-----------------|
| Fender, RH - 107 880 0180 | 1 |
| Fender, RH - 107 880 0280 | 1 |
| Door, LH - 107 720 0180 | 7 |
| Door, RH - 107 720 0280 | 7 |



If installing URO Parts' 6-piece **Body Molding Kit 1070582K**, a total of **(16)** new molding clips are recommended.

It's wise to have several extra new clips on hand, in case some are accidentally broken or lost during installation.



Installation by a professional technician is recommended. Refer to the factory repair manual for vehicle-specific service procedures for this part. Tighten all hardware to factory torque specifications and observe all repair manual cautions and warnings. Use safety stands whenever beneath a vehicle and always wear protective eyewear.